



Bed Sediment Photography and Analysis

*Effect of Urbanization on
Stream Bed Sediments in Anchorage*

by: Dennis Estis

Cook Inlet Basin NAWQA

<http://ak.water.usgs.gov/Projects/Nawqa>

destis@usgs.gov



U.S. Department of the Interior
U.S. Geological Survey

Background

- **Wolman pebble counts-** labor intensive, limited by depth of water
- **McNeil-** does not work in sediments much larger than 2mm (sand)
- **Freeze core-** takes time, involves heavy, cumbersome equipment, expensive

Objectives

- Find streambed sediment analysis method that allows ease of collection and yields quantitative results
- Develop photographic method for stream bed sediment analysis
- Determine effectiveness of photographic method by relating to Wolman counts and percent embeddedness.

Methods

- Photograph bed sediments at 3 points along each of the 11 transects per site
- Record point velocity and depth measurements at each point
- Determine scale in each photo, digitize surface pebbles, and areas of sand (less than 2mm)
- Measure intermediate axis lengths of surface pebbles
- Determine percent area of sand and particle size frequency distribution

Equipment

- 35mm SLR camera
- 28-70mm zoom lens
- Misc. filters- circular polarizer, neutral density, U.V. protector
- 12”diameter sample ring with scale bar
- Partially submergible bed sediment viewer with camera attachment

Equipment



Sediment Size Breaks

- Sand (>0.063-2 mm)
- Fine/ medium gravel (>2-16 mm)
- Coarse gravel (>16-32 mm)
- Very coarse gravel (>32-64 mm)
- Small cobble (>64-128 mm)
- Large cobble (>128-256 mm)
- Small boulder (>256-512 mm)
- Large boulder, irregular bedrock, irregular hardpan, irregular artificial surface (>512 mm)

Sample Photos




- 100 percent embedded (sand or finer- $< 2\text{mm}$)

Sample Photos



- Fine / medium gravel (>2-16 mm)

Sample Photos



- Coarse – very coarse gravel (>16-32 mm, >32-64 mm)


Sample Photos



- Small – large cobble (>64-128 mm, >128-256 mm)


Sediment Photography Analysis

- Determine scale
- Digitize areas of sand
- Digitize surface pebbles larger than 2mm
- Measure intermediate axis lengths (not shown)




Sediment Photography Analysis

- Determine scale
- Digitize areas of sand
- Digitize surface pebbles larger than 2mm
- Measure intermediate axis lengths (not shown)




Sediment Photography Analysis

- Determine scale
- Digitize areas of sand
- Digitize surface pebbles larger than 2mm
- Measure intermediate axis lengths (not shown)



Sediment Photography Analysis

- Determine scale
- Digitize areas of sand
- Digitize surface pebbles larger than 2mm
- Measure intermediate axis lengths (not shown)



Sediment Photography Analysis

- Determine scale
- Digitize areas of sand
- Digitize surface pebbles larger than 2mm
- Measure intermediate axis lengths (not shown)

